



BIG 3 WIRE KIT

Instructions

Thank You For Purchasing the Pure Power Product!

As a family owned and operated company we take great pride in the quality, value and performance of our products. This BIG 3 wire kit will give you years of trouble free performance providing you take care in following the simple instructions.

This BIG 3 wire kit is pre-assembled which allows you to install it fast and easy.

Designed with the do it yourselfer in mind, the BIG 3 kit can be completed with very few tools. Please see the steps below that will help you with a fast, safe and easy installation. Be sure to also clean connection points before installation to insure proper connection and ground.

Step 1 Connect the 30IN. BLACK GROUND CABLE between the Negative Battery Post and a solid chassis ground. This cable can either replace the existing ground, or can be used in addition to the existing ground cable.

Step 2 Connect one end of the 3FT. BLACK GROUND CABLE to the alternator mounting bolt, or engine block and the other end to the Negative Battery Post.

Step 3 Connect the remaining 4FT. RED POWER CABLE between the alternator B+ Stud and the Pos. Batt. Post and keep clear of moving engine components and extreme heat items like the radiator, valve covers and exhaust manifolds.

Step 4 Safely tie up and secure each individual cable with the provided ties.

Note: When stacking the ring terminals be sure to stack the highest guage terminal on the bottom of the stack. And leave all existing factory power and ground cables in place.

Use Precaution During Installation

Pay special attention and keep cables clear of moving parts like suspension parts and the drivetrain.

Keep cables and components away from extreme heat areas like the exhaust or manifold.

Always shield eyes. No spark, flame or smoking during installation.

Sulfuric Acid can cause severe burns and blindness.

Flush eyes immediately with water and get medical help immediately.

BIG 3 KIT

